

Construction Notes

- 1) Install backflow device square with hardscape elements as approved by the Public Works Inspector in the field.
- 2) Coordinate with Public Utilities-Water for location of backflow and water meter. Wherever possible, locate service and backflow in the parkway at mid-block a minimum of 150' from the Back of Curb Return at the nearest intersection per City standards.
- 3) The backflow enclosure must be locking Stainless Steel powder coated green per City specifications. SBBC-30-CR or Applicable size.
- 4) Backflow device shall be a Febco 825 YA installed using 250 psi rated brass/bronze pipe and fittings, between P.O.C. and device including the ninety degree elbows at the point of connection to the mainline. Contact Public Utilities-Water Backflow Program Staff (951) 351-6320 or (951) 351-6282 for inspection before back filling.

Approved P.V.	Date 4/23/08
Revised	Date
P.V.	7/9/08

Public Works Department, Forestry and Landscape Division
CITY OF RIVERSIDE

REDUCED PRESSURE BACKFLOW W/ENCLOSURE

Detail No. **2002**