



#### Construction Notes

- 1) Isolation valve must be Nibco T-113-K Gate Valve.
- 2) Where pipe depth must change, use 45 degree elbows.
- 3) A minimum of 2 CF. of 3/4" gravel rock shall be placed under valve in box.
- 4) Install valve box so that the box does not rest on any lateral or main lines.
- 5) Provide minimum 3' clear distance between valve and wire boxes.

Approved P.V.	Date 5/27/08
------------------	-----------------

Public Works Department, Forestry and Landscape Division  
CITY OF RIVERSIDE

Revised Detail No.	Date
-----------------------	------

ISOLATION VALVE IN BOX

Detail No.

**2015**