

Street:

SOVEREIGN WAY

X-Street:

PERCIVAL DRIVE

OFFICIAL USE ONLY

SWING TIES

() - REC. DIST. PER. TIE SHT. FOR TR. 18505

DRIVE

FD NOTHING @ SURFACE

PERCIVAL

FD 1" I.P. W/RCE11842 TAG FLUSH RESET W/P.K. NAIL + CITY SUR TAG FLUSH

SOVEREIGN WAY

(4156)
(1473)
(4906)
(5342)

● FD RAMSET + RCE11842 ON T/C

- × FD. Ramset Nail on T/C ● FD. LD. & TK. on T/C
- FD. "C" Nail on T/C ○ Set LD. & TK. on T/C

P.K. and City Engineer tag to be set @ surface after street construction is complete. (If possible)

Scale: 1" = 40'

Date: 02/08/06

Drawn by: survey

F.B.:

TR-Sec: T3SR5W-2

OFFICIAL TIE PLAT

CITY OF RIVERSIDE

These ties are for the purpose of perpetuating the found monumentation. No claim is made as to the relationship of the points or lines shown hereon to true boundary locations.



Sheet 1 of 1

Cadme MB: 54-8