



- Legend**
- 1 remove exist curb and gutter
 - 2 remove exist A.C. berm
 - 3 form grade break
 - 4 match exist. construction
 - 5 place 3" AC over 6" C&G
 - 6 construct Curb and Gutter Std. 200, 6" C.F.
 - 7 construct Curb and Gutter Std. 200, 8" C.F.
 - 8 remove portion of A.C. swale. Construct Catch Basin Std. 405 (4'aceting, V.17B'). Install 8" of 15" conc. or asbestos cement pipe, class 1500. Place A.C. around pipe outlet.
 - 9 overlay exist. A.C.
 - 10 trim tree branches
 - 11 remove tree
 - 12 relocate reflector post unit
 - 13 relocate fence
 - 14 relocated fence, 8' from curb line
 - 15 construct A.C. term Std. 250

CITY OF RIVERSIDE, CALIFORNIA DEPARTMENT OF PUBLIC WORKS		PROJECT NO. R-1443	
APPROVED BY: <i>[Signature]</i> DATE: 11/16/70		APPROVED BY: <i>[Signature]</i> DATE: 11/16/70	
HORIZ. SCALE: 1" = 20' VERT. SCALE: 1" = 2'		FILE NO.	